

Specs for the Quick Response Transport

- ✓ Provide and install workstation desk base structure
- ✓ Provide and install desk counter
- ✓ Provide and install chair tie downs under workstation
- ✓ Provide and install OTS 2- drawer base cabinet, right side under workstation countertop
- ✓ Provide rolling office style chair, secured when in motion
- ✓ Provide and install Whelen 295SLSA6 siren
- ✓ Provide and install Whelen SA315P with bracket
- ✓ Provide and install Whelen M6 series Super LED Warning lights red
- ✓ Provide and install Whelen M6 Chrome flanges
- ✓ Provide and install Whelen M9 series Super LED Warning Light Red
- ✓ Provided and install M9 chrome flanges
- ✓ Provided and install Whelen Ion warning lights RED
- ✓ Provide and install Whelen M9LZC Gradient LED Scene Lights
- ✓ Provide and install Circuit protection and power distribution for warning
- ✓ Provide and Install Shore Power and 30A to 15A Shoreline Adapter
- ✓ Modify rear existing body for installation of taller rear door
- ✓ (2) 12 V DC Battery System with Isolators and power distribution system
- ✓ Installed 30-amp 50 ft shore power cord w/ adapter
- ✓ (3) interior 15-amp duplex outlets with USB
- ✓ (1) exterior 15-amp duplex GFCI outlet
- ✓ (1) Xantrex Freedom X2000 Inverter w/ remote panel
- ✓ Install Xantrex TrueCharge 40. Wired: to charge Battery
- ✓ Install power distribution and circuit protection for system
- ✓ Install custom manual transfer switch for AC source input (3 position +off)
- ✓ Install Cummins 7kw gas generator
- ✓ Install Control Panel
- ✓ Install fuel tap system in fuel tank
- ✓ Install AGM battery for generator
- ✓ Install additional Penquin II Heat Pump 13,500 btu
- ✓ Install CO2 detector
- ✓ \$4,000 allowance for Graphics

This vehicle could be on a Sprinter/Transit/Dodge Ram Promaster