



Required Packages

Total Pro AI Kit
PN: 7035069

QuickMap 3D® Android Data Collector Basic Pkg
PN: 7035165

1 TruSpeed® Sxb
PN: 7007051

2 Mounting Assembly, 360R/TSSx/Sxb
PN: 7024866

3 UltraLyte Yoke w/ a Mount
PN: 7034235

4 LTI Staff
PN: 3504236

5 Bi-Pod Legs
PN: 3504272

6 5/8 to 1/4-20 Brass Adaptor
PN: 3003021

7 Tripod/Prism Sherpa
PN: 3123473

8 Foliage Filter with Tether
PN: 7035142

9 Rugged Android™ Tablet
PN: 3255133

10 QuickMap 3D Android Software
PN: 3204724-E

11 Tablet X-Grip Cradle
PN: 3255096

12 Claw Mounting Base w/ Arm
PN: 3255097