

The tribrach is used to hold the TruAngle and is mainly so leveling the instrument is easier than doing it with the tripod legs.

When you do this before starting to map the scene you need to make sure of your control point for the scene. So, the laser plummet in the tribrach assembly allows the user to drop a laser beam at the spot and then they would mark it with road nails or some other fixed object. In this way they do not need to drop a plumb bob on the control point, so it is much easier for the user.

