



Always use safety stands when installing or removing heavy components.



Portable Maintenance Jack Stands

RS20YL / Screw-Type Adjustable

56.1"-82.3" / 20,000 lbs. Capacity

RS20WYL / Welded Version of RS20YL

RS2052SYL / Screw-Type Adjustable

34.3 "-55.5" / 20,000 lbs. Capacity

RS36SYL / Screw-Type Adjustable

55.31"-82.28" / 36,000 lbs. Capacity

All jack stands meet the required ASME
PASE-2014 safety requirements for portable
service equipment.